


Instruction Manual



Caution

- a Fixing screws are for use on wood only.
- b Do not hang from the curtain rail.
- c Exercise care to avoid injury when cutting the rail.
- d Make sure that furring strips have been placed at the mounting point before installing.

Product View and Part Names





Installation Procedure

- 1 Mount brackets with fixing screws at positions within 5cm from the ends, and the portion there between at intervals of within 35cm.

* For better appearance, mount brackets at both sides of a curved portion.


Caution
• When fitting fixing screws into a hard or thin wooden frame, be sure to drill pilot holes before tightening the fixing screws. If too much force is applied when fitting the screws, the head of the fixing screws or the wooden frame may break.



- 2 Temporarily attach the rail to the fixed brackets at the end, and determine the rail length.

* Curling of the rail can be straightened by bending the rail toward the opposite side.

Caution
• When temporarily attaching the rail, only lightly press the bracket fingers. Be sure not to push them in deeply.



3


Detach the rail from the brackets, and cut away any excess portion with a cutter or hand saw.

* When cutting the rail with a cutter, cut away any excess portion of the rail as indicated, and bend the rail back and forth several times.



Caution


• When cutting the rail with a cutter, please be careful not to get injured.




- 4 Remove the cap stop from the portion cut off, and put it on the end of the rail to be attached.

- 5 Attach the rail to the brackets at one end, adjust the position, and then push in the fingers to fix the rail.


* The fingers can be easily pushed in with a screwdriver in hard areas.



- Removing the rail
To remove the rail, use a screwdriver to lift the fingers gripping the bracket.



Installation Diagram (unit: mm)



Number of Parts

Name of Part	2.0m Set	3.0m Set
Rail	2.0m (1pc)	3.0m (1pc)
Cap stop	2pcs.	2pcs.
Roller	22pcs	34個
Magnet roller	1pair	1pair
Bracket	9pcs.	12pcs.
Fixing screw (M3.1x20)	9pcs.	12pcs.

Materials

<Product>

Rail	Low density polyethylene
Cap stop	Nylon resin
Roller (Magnet Roller)	Main body: High density polyethylene Wheel: Polyacetal resin
Bracket	Main body: Coated steel Finger: ABS resin

<Packing material>

Outer bag	Polypropylene	♻️ 5 PP
Individual packaging for components	Low density polyethylene	♻️ 4 LDPE
Label	Recycled paper	